

Tool Box Vehicle Guide	Scout				Garrison																						
	Single Lid				Gull Wing	Single Lid																					
	Full Size	Down size	FS Low Pro	DS Low Pro	Low Pro Narrow	Full Size	Down size	Full Size	Super Duty	FS & SD Low Pro	FS Narrow Low Pro	Full size Deep	Super Duty Deep	FS/SD Deep LoPro	FS Wide & Deep	FS Wide & Deep LP	Down Size	Down Size Low Pro	DS Import	Splash/S10 Sportside	Fs Chev Sportside	Old Tundra	Mid Size	Mid Size Low Pro	Mid Size	Mid Size Deep	MS Crew Low Pro
40101	40102	40201	40202	40002	40301	40302	41001	41004	41501	41012	41002	41006	41502	41008	41508	41003	41503	41009	41011	41010	41005	41007	41507	41013	41014	41515	
Chevy/GMC																											
70-11 Full Size	X		X		X	X		X		X	X	X		X	X	X											
07-11 Full Size 5.8' Bed	X		X		X	X		X		X	X																
88-02 Full Size Sportside																					X						
04-11 Cany/Colorado(No Crew)																							X	X	X	X	
04-11 Canyon/Colo Crew																										X	
92-06 S-10/S-15 (No Crew)		X		X			X										X	X	X								
01-04 S-10/S-15 Crew																											
Dodge																											
09-11 Ram LD 10-11 Ram HD	X		X		X	X		X		X	X	X		X	X	X											
09-11 Ram 1500 5.6' Bed	X		X		X	X		X		X	X																
02-8 Ram 1500 03-9 Ram HD	X		X		X			X		X	X		X	X	X												
94-02 Ram	X		X		X	X		X		X	X	X		X	X	X											
78-93 Full Size	X		X		X	X		X		X	X	X		X	X	X											
05-09 Dakota Crew Cab																								X	X	X	
05-09 Dakota Club Cab																						X	X	X	X		
87-04 Dakota (No Crew)																						X	X				
Ford																											
04-11 F150 (No SuperCrew)	X		X		X	X		X		X	X	X		X	X	X											
04-11 F150 SuperCrew 5.6'					X					X	X																
06-11 F150 SuperCrew 6.5'	X		X		X	X		X		X	X	X		X	X	X											
97-03 F150/F250 (LD)	X		X		X	X		X		X	X	X		X	X	X											
01-03 F150 SuperCrew					X						X																
97-08 F150 Flareside																						X					
87-96 F Series	X		X		X	X		X		X	X	X		X	X	X											
87-96 F150 Flareside																					X						
99-11 Super Duty	X		X		X			X		X			X	X	X	X											
97-98 F250/F350 HD	X		X		X	X		X		X		X		X	X	X											
83-11 Ranger (No Edge)		X		X			X										X	X	X								
93-01 Rang Splash (No Edge)																				X							
Toyota																											
07-11 Tundra	X		X		X	X		X		X	X	X		X	X	X											
00-06 Tundra																						X					
93-99 T100																						X					
05-11 Tacoma - no crew																							X	X	X	X	
05-11 Tacoma Crew Cab																								X	X	X	
89-04 Tacoma				X															X								

This is a general guide - please check application using tool box measurements from pages 34-38 for verification prior to ordering product paying close attention to bed rail track systems on newer vehicles, bed liners, wheel well openings, extra short and step side beds.

