



Tool Box Vehicle Guide	Scout						Garrison																					
	Single Lid					Gull Wing	Single Lid																					
	Full Size	Down size	FS Low Pro	DS Low Pro	Low Pro Narrow	Full Size	Down size	Full Size	Super Duty	FS & SD Low Pro	FS Narrow Low Pro	Full size Deep	Super Duty Deep	FS/SD Deep LoPro	FS Wide & Deep	FS Wide & Deep LP	Down Size	Down Size Low Pro	DS Import	Splash/S10 Sportside	Fs Chev Sportside	Old Tundra	Mid Size	Mid Size Low Pro	Mid Size	Mid Size Deep	MS Crew Low Pro	
40101	40102	40201	40202	40002	40301	40302	41001	41004	41501	41012	41002	41006	41502	41008	41508	41003	41503	41009	41011	41010	41005	41007	41507	41013	41014	41515		
Chevy/GMC																												
70-11 Full Size	X		X		X	X		X		X	X	X		X	X	X												
07-11 Full Size 5.8' Bed	X		X		X	X		X		X	X																	
88-02 Full Size Sportside																					X							
04-11 Cany/Colorado(No Crew)																							X	X	X	X		
04-11 Canyon/Colo Crew																											X	
92-06 S-10/S-15 (No Crew)		X		X			X										X	X	X									
01-04 S-10/S-15 Crew																											X	
Dodge																												
09-11 Ram LD 10-11 Ram HD	X		X		X	X		X		X	X	X		X	X	X												
09-11 Ram 1500 5.6' Bed	X		X		X	X		X		X	X																	
02-8 Ram 1500 03-9 Ram HD	X		X		X	X			X	X	X		X	X	X													
94-02 Ram	X		X		X	X		X		X	X	X		X	X	X												
78-93 Full Size	X		X		X	X		X		X	X	X		X	X	X												
05-09 Dakota Crew Cab																									X	X	X	
05-09 Dakota Club Cab																							X	X	X	X		
87-04 Dakota (No Crew)																						X	X					
Ford																												
04-11 F150 (No SuperCrew)	X		X		X	X		X		X	X	X		X	X	X												
04-11 F150 SuperCrew 5.6'					X	X				X	X																	
06-11 F150 SuperCrew 6.5'	X		X		X	X		X		X	X	X		X	X	X												
97-03 F150/F250 (LD)	X		X		X	X		X		X	X	X		X	X	X												
01-03 F150 SuperCrew					X	X				X	X																	
97-08 F150 Flareside																						X						
87-96 F Series	X		X		X	X		X		X	X	X		X	X	X												
87-96 F150 Flareside																					X							
99-11 Super Duty	X		X		X	X			X	X			X	X	X	X												
97-98 F250/F350 HD	X		X		X	X		X		X			X	X	X	X												
83-11 Ranger (No Edge)		X		X			X										X	X	X									
93-01 Rang Splash (No Edge)																				X								
Toyota																												
07-11 Tundra	X		X		X	X		X		X	X	X		X	X	X												
00-06 Tundra																						X						
93-99 T100																						X						
05-11 Tacoma - no crew																							X	X	X	X		
05-11 Tacoma Crew Cab																								X	X	X	X	
89-04 Tacoma				X															X								X	

This is a general guide - please check application using tool box measurements from pages 34-38 for verification prior to ordering product paying close attention to bed rail track systems on newer vehicles, bed liners, wheel well openings, extra short and step side beds.



Tool Box Vehicle Guide

Add (B) to end of part number for Black Powder Coat Finish - Numbers with plus sign (+) are not available in Black

Garrison

	Garrison																	
	Gull wing				Side Mount				Top Sider			RV Chest				Wheel Well		
	Full size	Full Size Deep	Super Duty	Down Size	Full Size 48"	Full Size 60"	Full Size 72"	Down Size 48"	72"	90"	96"	60" Slant Front	60" Slant Sides	55" Slant Front	44"	36"	Medium	Large
43001	43002	43003	43005	42001	42002	42003	42006	46001+	46002+	46003+	44001	44008	44002	44004	44003	42004	42005	
Chevy/GMC																		
70-11 Full Size	X	X			X	X	X		X	X	X	X		X	X	X		X
07-11 Full Size 5.8' Bed	X				X													
88-02 Full Size Sportside															X	X		
04-11 Canyon/Colorado (Except Crew)					X			X							X	X	X	
04-11 Canyon/Colorado Crew Cab																		
92-06 S-10/S-15 (Except Crew Cab)				X				X							X	X	X	
01-04 S-10/S-15 Crew Cab								X								X	X	
Dodge																		
09-11 Ram LD 10-11 Ram HD	X	X			X	X	X		X	X	X		X	X	X	X		X
09-11 Ram 1500 5.6' Bed	X				X										X	X		X
02-08 Ram 1500 03-09 Ram 2500 3500	X	X	X		X	X	X		X	X	X		X		X	X		X
94-02 Ram	X	X			X	X	X		X	X	X	X		X	X	X		X
78-93 Full Size	X	X			X	X	X		X	X	X	X		X	X	X		X
05-09 Dakota Crew Cab																		
05-09 Dakota Club Cab					X			X							X	X	X	
87-04 Dakota (Except Crew)					X			X							X	X	X	
Ford																		
04-11 F150 (except SuperCrew)	X	X			X	X	X		X	X	X	X		X	X	X		X
04-11 F150 SuperCrew 5.6 'Bed					X										X	X		X
06-11 F150 SuperCrew 6.5' Bed	X	X			X	X	X		X			X		X	X	X		X
97-03 F150/F250 (Light Duty)	X	X			X	X	X		X	X	X	X		X	X	X		X
01-03 F150 SuperCrew Cab					X	X								X	X	X		
97-08 F150 Flareside					X										X	X		
87-96 F Series	X	X			X	X	X		X	X	X	X		X	X	X		X
87-96 F150 Flareside					X										X	X		
99-11 Super Duty	X	X	X		X	X	X		X	X	X		X	X	X	X		X
97-98 F250/F350 Heavy Duty	X	X			X	X	X		X	X	X	X		X	X	X		X
83-11 Ranger (Except Edge)				X				X							X	X	X	
93-01 Ranger Splash (Except Edge)								X							X	X		
Toyota																		
07-11 Tundra	X	X			X	X	X		X	X	X			X	X	X		X
00-06 Tundra					X	X			X					X	X	X		X
93-99 T100					X	X			X					X	X	X		X
05-11 Tacoma - no crew								X							X	X	X	
05-11 Tacoma Crew Cab																		
89-04 Tacoma				X				X							X	X	X	

This is a general guide - please check application using tool box measurements from pages 34-38 for verification prior to ordering product paying close attention to bed rail track systems on newer vehicles, bed liners, wheel well openings, extra short and step side beds.



Tool Box Vehicle Guide	Ellipse XPL Paddle Latch and Ellipse Push Button Single Lid																										
	Ellipse XPL Low Pro				Ellipse XPL Standard						XPL Chests				Ellipse Push Button Low Pro												
	Full Size	Full size Deep	FS Narrow & Deep	FS Wide & Deep	Down Size Narrow	DS Narrow & Deep	Full Size	Full Size Deep	FS Wide & Deep	Mid Size	Down Size	Down Size Import	Side Mount 48"	Side Mount 56"	Side Mount 78"	60" RV Slant Front	60" RV Slant Sides	44" Utility	36" Utility	Full Size	Mid Size	Down Size	Down Size Import	Extra Wide & Deep	48" Side Mount	56" Side Mount	72" Side Mount
57501	57502	57512	57508	57525	57526	57001	57002	57008	57007	57003	57009	57201	57202	57203	57401	57408	57404	57403	56001	56002	56003	56004	56005	56201	56202	56203	
<i>Add (B) to end of part number for Black Powder Coat Finish - Numbers with plus sign (+) are not available in Black</i>																											
Chevy/GMC																											
70-11 Full Size	X	X	X	X			X	X	X				X	X	X	X		X	X	X				X	X	X	X
07-11 Full Size 5.8' Bed	X		X				X						X							X					X		
88-02 Full Size Sportside													X	X	X			X	X						X	X	X
04-11 Canyon/Colo (NoCrew)									X				X					X	X		X						
04-11 Can/Colorado Crew Cab																											
92-06 S-10/S-15 (No Crew)					X	X				X	X							X	X			X	X				
01-04 S-10/S-15 Crew Cab					X														X								
09-11 Ram LD 10-11 Ram HD	X	X	X	X			X	X	X				X	X	X		X	X	X	X				X	X	X	X
09-11 Ram 1500 5.6' Bed	X		X				X	X					X	X	X		X	X	X					X	X	X	X
02-8 Ram 1500 03-9 Ram HD	X	X	X				X	X					X	X	X		X	X	X						X	X	X
94-02 Ram	X	X	X	X			X	X	X				X	X	X	X		X	X	X				X	X	X	X
78-93 Full Size	X	X	X	X			X	X	X				X	X	X	X		X	X	X				X	X	X	X
05-09 Dakota Crew Cab																											
05-09 Dakota Club Cab									X				X					X	X								
87-04 Dakota (No Crew)									X				X					X	X								
04-11 F150 (No SuperCrew)	X	X	X	X			X	X	X				X	X	X	X		X	X	X				X	X	X	X
04-11 F150 SuperCrew 5.6'			X										X	X				X	X						X	X	X
06-11 F150 SuperCrew 6.5'	X	X	X	X			X	X	X				X	X	X			X	X	X				X	X	X	X
97-03 F150/F250 (LD)	X	X	X	X			X	X	X				X	X	X	X		X	X	X				X	X	X	X
01-03 F150 SuperCrew			X										X	X				X	X					X	X	X	X
97-08 F150 Flareside													X	X				X	X					X	X	X	X
87-96 F Series	X	X	X	X			X	X	X				X	X	X	X		X	X	X				X	X	X	X
87-96 F150 Flareside													X	X				X	X					X	X		
99-11 Super Duty	X	X		X			X	X	X				X	X	X		X	X	X	X				X	X	X	X
97-98 F250/F350 HD	X	X		X			X	X	X				X	X	X	X		X	X	X				X	X	X	X
83-11 Ranger (Except Edge)					X	X					X	X						X	X			X	X		X	X	
93-01 Rang Splash (No Edge)																		X	X					X			
07-11 Tundra	X	X	X	X			X	X	X				X	X	X			X	X	X				X	X	X	X
00-06 Tundra													X	X	X			X	X					X	X	X	X
93-99 T100													X	X	X			X	X					X	X	X	X
05-11 Tacoma - no crew									X									X	X		X						
05-11 Tacoma Crew Cab																											
89-04 Tacoma					X	X												X	X				X	X			

This is a general guide - please check application using tool box measurements from pages 34-38 for verification prior to ordering product paying close attention to bed rail track systems on newer vehicles, bed liners, wheel well openings, extra short and step side beds.